## INDOOR / DOWNLIGHTS / PRO WALLWASH

Código artículo 86.D066.3453.01





## INDOOR / DOWNLIGHTS / PRO WALLWASH

Código artículo 86.D066.3453.01



5. Fold up the three shrapnel of the downlight, then install the downlight to the hole as shown to make sure the downlight cannot fall off.



6. Make sure the distance between the downlight and the object as shown. The downlight cannot be covered.



7. Switch it on to check the lighting effect and adjust the lamp direction for the target of accent lighting. Installation accomplished  $\,$   $\,$ 



