








- 1 Open the ceiling hole in accordance to the given luminaire cut hole size. The suitable false/plaster ceiling thickness shall be 2-25mm.
 
- 2 Detach the frame, led module and reflector of the luminaire.
 
- 3 Glue the frame to the ceiling and fix it with screws.
 
- 4 Apply white paint and cover the frame.
 
- 5 Turn off the main switch.
 
- 6 Disconnect the electrical power, connect the electrical "L" and "N" wire to led driver.
 
- 7 Insert the driver and luminaire led module into the frame hole.
 
- 8 Install the driver, and the lamps should be installed as shown in the figure.
 
- 9 Insert the reflector into the groove slot. Complete the installation and clean the surface of the luminaire.
 
- 10 Luminaire is ready to connect to electrical power.
 