



1. Use a hammer drill to drill a hole with a diameter of 8 mm.



1

2. Place two M6 iron expansion into the holes.




2

3. Fix the fixture with the screws and expansion bolt




3

4. Wiring method:



4

5. Wrap the wiring wire with waterproof tape.



5