



**1** Connector  
Screws  
First, connect the wire. Second, install the connector. Third, fix the screws.

**2** Connector  
Screws  
First, connect the wire. Second, install the connector. Third, fix the screws.

**3**  
Install the profiles top cover.

**4** Screws  
x8pcs  
After install the profiles top cover, fixed them with screws.

**5**  
Fill the gap with our glue.

**6**  
Make glue smooth with a scraper.

**7**  
x4 n pcs  
First, make marks on the ceiling, then dig holes.

**8**  
For Small box  
x2pcs  
Second, fixed the terminals of the pendant suit and box holder with screws

**9**  
x4 n pcs  
Install the terminals of the pendant suit.

**10**  
Install the lamp as the picture shows.

**11** If the driver is **dimming & internal** installation  
Dimming wire  
Driver  
Small box  
Input wire AC-  
Color for wires:  
AC-L (Blue)  
AC-N (Black)  
GND (Green)  
DIM-(DA1) (Red)  
DIM-(DA2) (Yellow)  
Connect the wires correctly as above showing.

**12** If the driver is **non-dimming & internal** installation  
Driver  
Small box  
Input wire AC-  
Color for wires:  
AC-L (Blue)  
AC-N (Black)  
GND (Green)  
Connect the wires correctly as above showing.

**13**  
x2pcs  
Install the small box as above showing.

**14**  
Finished