



- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

### Cut out in the right size

|                 |         |
|-----------------|---------|
| 86.D025.0***.** | 75mm    |
| 86.D025.1***.** | 75mm    |
| 86.D025.2***.** | 85mm    |
| 86.D025.3***.** | 95mm    |
| 86.DS25.1***.** | 75mm    |
| 86.DS25.2***.** | 85mm    |
| 86.DS25.3***.** | 95mm    |
| 86.D026.1***.** | 75*75mm |
| 86.D026.2***.** | 85*85mm |
| 86.D026.3***.** | 95*95mm |
| 86.DS26.1***.** | 75*75mm |
| 86.DS26.2***.** | 85*85mm |
| 86.DS26.3***.** | 95*95mm |

