



- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

Cut out in the right size: 86.D084.0\*\*\*. 55mm, 86.D084.1\*\*\*. 75mm, 86.D084.2\*\*\*. 95mm, 86.D085.0\*\*\*. 55\*55mm, 86.D085.1\*\*\*. 75\*75mm

86.D085.2\*\*\*. 95\*95mm, 86.D086.0\*\*\*. 57mm, 86.D086.1\*\*\*. 77mm, 86.D086.2\*\*\*. 97mm

86.D087.0\*\*\*. 57\*57mm, 86.D087.1\*\*\*. 77\*77mm, 86.D087.2\*\*\*. 97\*97mm, 86.DS84.1\*\*\*. 75mm, 86.DS84.2\*\*\*. 95mm  
86.DS85.1\*\*\*. 75\*75mm, 86.DS85.2\*\*\*. 95\*95mm, 86.DS86.1\*\*\*. 77mm, 86.DS86.2\*\*\*. 97mm, 86.DS87.1\*\*\*. 77\*77mm  
86.DS87.2\*\*\*. 97\*97mm, 86.D284.0\*\*\*. 128\*67mm, 86.D284.1\*\*\*. 179\*91mm, 86.D284.2\*\*\*. 223\*112mm  
86.D285.0\*\*\*. 122\*60mm, 86.D285.1\*\*\*. 164\*77mm, 86.D285.2\*\*\*. 207\*95mm, 86.D286.0\*\*\*. 128\*67mm  
86.D286.1\*\*\*. 180\*90mm, 86.D286.2\*\*\*. 225\*111mm, 86.D287.0\*\*\*. 118\*58mm, 86.D287.1\*\*\*. 165\*77mm  
86.D287.2\*\*\*. 209\*97mm

