



- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

Cut out in the right size:

MINIPPOINT

86.D018.1***.**	35mm
86.D018.2***.**	35mm
86.D018.3***.**	50mm
86.D018.4***.**	50mm

MINIPPOINT-A

86.D019.1***.**	47mm
86.D019.2***.**	47mm
86.D019.3***.**	62mm
86.D019.4***.**	65mm

