



- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

Cut out in the right size:

**MINIPOINT**

|                 |      |
|-----------------|------|
| 86.D018.1***.** | 35mm |
| 86.D018.2***.** | 35mm |
| 86.D018.3***.** | 50mm |
| 86.D018.4***.** | 50mm |

**MINIPOINT-A**

|                 |      |
|-----------------|------|
| 86.D019.1***.** | 47mm |
| 86.D019.2***.** | 47mm |
| 86.D019.3***.** | 62mm |
| 86.D019.4***.** | 65mm |

