



- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

Cut out in the right size:

86.DS22/D022.1\*\*\*.\*\* 75mm  
86.DS22/D022.2\*\*\*.\*\* 95mm  
86.DS22/D022.3\*\*\*.\*\* 120mm  
86.DS22/D022.4\*\*\*.\*\* 175mm  
86.DS22/D022.5\*\*\*.\*\* 200mm  
86.DS22/D022.6\*\*\*.\*\* 200mm  
86.DS22/D022.5\*\*\*.\*\* 240mm

Cut out in the right size:

86.D023.1\*\*\*.\*\* 95\*95mm  
86.D023.2\*\*\*.\*\* 140\*140mm  
86.D023.3\*\*\*.\*\* 200\*200mm

