





- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.


Product Dimensions (mm)




Installation Method 1






Installation Accessories




Installation Method 2



Installation Method 3



Control System Diagram



max Power 15W/M, with 5 Pin Cable: Red V+ / Green A / Blue B / Yellow W / Black GND. One controller with 8 DMX outputs, each takes max 32 meters