



- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

Cut out in the right size:

MINIPOINT

- 86.D018.1\*\*\*.\*\* 35mm
- 86.D018.2\*\*\*.\*\* 35mm
- 86.D018.3\*\*\*.\*\* 50mm
- 86.D018.4\*\*\*.\*\* 50mm

MINIPOINT-A

- 86.D019.1\*\*\*.\*\* 47mm
- 86.D019.2\*\*\*.\*\* 47mm
- 86.D019.3\*\*\*.\*\* 62mm
- 86.D019.4\*\*\*.\*\* 65mm

