



- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

Cut out in the right size:

- 86.DS22/D022.1***.** 75mm
- 86.DS22/D022.2***.** 95mm
- 86.DS22/D022.3***.** 120mm
- 86.DS22/D022.4***.** 175mm
- 86.DS22/D022.5***.** 200mm
- 86.DS22/D022.6***.** 200mm
- 86.DS22/D022.5***.** 240mm

Cut out in the right size:

- 86.D023.1***.** 95*95mm
- 86.D023.2***.** 140*140mm
- 86.D023.3***.** 200*200mm

