



- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

Cut out in the right size

86.D025.0***.** 75mm

86.D025.1***.** 75mm

86.D025.2***.** 85mm

86.D025.3***.** 95mm

86.DS25.1***.** 75mm

86.DS25.2***.** 85mm

86.DS25.3***.** 95mm

86.D026.1***.** 75*75mm

86.D026.2***.** 85*85mm

86.D026.3***.** 95*95mm

86.DS26.1***.** 75*75mm

86.DS26.2***.** 85*85mm

86.DS26.3***.** 95*95mm

