




- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- **DO NOT** make or alter any open holes in the luminaire. Do not modify the luminaire.
- **DO NOT** install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.




01

Make a hole at the desired installation location according to the fixture's opening size.



02

Thread the reserved power cable through the light fixture housing, then press the spring on the light fixture housing upward, and insert the light fixture housing into the ceiling.



03

Connect the driver input to the reserved power supply line, insert the driver into the ceiling, then insert the light-emitting module into the lamp housing. Press the lamp housing until you hear a 'click' sound to secure the light-emitting module. To remove the light-emitting module, gently press the sides of the lamp module to pop it out. When installing or removing the light-emitting module, try to press both sides simultaneously to keep them synchronized.



04

Installation complete, turn on the circuit breaker, and test the light.