





- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation,inspection,and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

This is not an included accessory and need to be sourced seperately.




## **Rotatable Angle**


loosen the sreawes 18 29N.m







## **Connect Wires**







Warning! Do not wire dim cord to high voltage, or dim function will fail.

## DIM cords

Note: color for dim cords subject to the cable label on luminaire

