









- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

This is not an included accessory and need to be sourced separately.




**Rotatable Angle**

loosen the screws



**Connect Wires**



**AC cords**

<b>L</b>	brown		black
<b>N</b>	blue		white
⊕	yellow/green		green



**Warning!** Do not wire dim cord to high voltage, or dim function will fail.

**DIM cords**

Note: color for dim cords subject to the cable label on luminaire