





- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- **DO NOT** make or alter any open holes in the luminaire. Do not modify the luminaire.
- **DO NOT** install damaged product.
- Make sure electrical power is **OFF** before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.


Ceiling-mounted installation
1

AC 220V mains power

Attach the ceiling rose to the ceiling using the provided screws.

2

Connect the reserved wires to the lamp's power supply, then tighten the lamp to the ceiling mount.

3


Use the screws provided with the fixture to secure the light to the ceiling.

After installation, turn on the power to check if the light works.

Wall-mounted installation method
1


AC 220V mains power

Install the mounting plate on the ceiling with the provided screws, leaving space for the power supply wires.

2

AC 220V mains power

Connect the reserved power supply wire to the lighting fixture power wire

3

Use the screws provided with the fixture to secure the light to the ceiling.
 After installation, turn on the power to check if the light works.