
INDOOR / TRACKLIGHTS / MAGNETIC TRACK / MAGNETIC TRACK **ACCESORIES**










• Installation, inspection, and maintenance of luminaires should be performed by a qualified

- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.







Note: The positive and negative (+, -) signal terminal of 0-10V dimming luminous must be installed corresponding to the input terminal.

The positive and negative (+, -) signal terminal of DALI dimming luminous, the signal termial does not need to be installed corresponding to the input termial.

