

**INDOOR / ARCHITECTURAL
LUMINAIRES / WORKSTATION /
WORKSTATION FLOOR**




Item code 86.A009.1492.02





- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
- DO NOT install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.

LAVOV
LIGHTING


1



Accessory

Screw A		AX4
Screw B		BX4
Cross point screwdriver		X1
Hexagon screwdriver		X1


2



AX4


Fix the bottom pole onto base plate

3




Open the box of lamp body

4



Connect the terminals body


5



BX4


Fix the lamp holder with the B screws

6





Close the box by screws

7



Insert the tail of the AC cable into the terminal seat of lamp pole.

8



LAVOV
LIGHTING

info@lavovlighting.com | lavovlighting.com