










► RECESSED IN A CUT-OUT HOLE






Accessories	3030	3040	4040	6262	30120	60120
		X 4			X 6	







► RECESSED IN FALSE-CEILING FRAME












► **SUSPENSION**

Accessories	3030	3060	6060	4262	30120	60120
		X 2			X 3	
		X 2			X 3	
		X 4			X 6	
		X 2			X 3	
		X 2			X 3	







► CEILING & WALL MOUNTED

Accessories	3030	3040	4040	6242	30120	60120
 Speaker		X 4			X 6	
 Microphone		X 4			X 6	
 Pen		X 4			X 6	
 Eraser		X 4			X 6	
 Pencil		X 4			X 6	



► **FRAME MOUNTED**

Accessories	3030	3040	6040	6342	30120	60120
<b>Frame A</b> 		X 2			X 2	
<b>Frame B</b> 		X 2			X 2	
		X 8			X 8	
		X 4			X 6	

