





► RECESSED IN A CUT-OUT HOLE






Accessories	3030	3040	6040	6262	30120	60120
		X 4			X 6	




► RECESSED IN FALSE-CEILING FRAME










► **SUSPENSION**

Accessories	3030	3060	6060	6262	30120	60120
		X 2			X 3	
		X 2			X 3	
		X 4			X 6	
		X 2			X 3	
		X 2			X 3	







► CEILING & WALL MOUNTED

Accessories	3030	3040	4040	6242	30120	60120
 Speaker		X 4			X 6	
 Microphone		X 4			X 6	
 Headset		X 4			X 6	
 Pen		X 4			X 6	
 Screwdriver		X 4			X 6	
 Wrench		X 4			X 6	



► **FRAME MOUNTED**

Accessories	3030	3040	4040	4242	30120	40120
Frame A 		X 2			X 2	
Frame B 		X 2			X 2	
		X 8			X 8	
		X 4			X 6	

