



## STEP 1





Install the nozzle head on the pipe of the water outlet.

## STEP 2




Twist the lamp into the nozzle head in the direction of the spiral teeth.

## STEP 3




Connet the power supply and fixtures cable using IP connector. Make sure the waterproof is good.

## STEP 4




Then lock the waterproof connector.

## CONNECTION DIAGRAM

