
Código artículo 86.S008.1030.29



1. Fix the hanging board, connect the power supply, and install the lighting fixtures



2. Pull out the positioning key and install the lampshade

