

4 Wire (3-Phase) Rail







Adapter



Integrated Adapter

### Adapter Installation Instructions




1. Make sure the track adapter's positions are the same as the picture showed before installation.

2. The adapter flange is in the same direction with the track plane.


3. Track adapter into the track.

4. Revolve the hand grip in place, select the power knob: phase 1/ phase 2/ phase 3. Can swing clockwise and anticlockwise.

### Remove Instructions






Turn the hand grip to the position as shown



Remove the track adapter as shown

### Integrated Adapter Installation Instructions




1. Make sure the track adapter's positions are the same as the picture showed before installation.

2. The adapter flange is in the same direction with the track plane.


3. Track adapter into the track.

4. Revolve the hand grip in place, select the power knob: phase 1/ phase 2/ phase 3. Can swing clockwise and anticlockwise.

### Remove Instructions



Turn the hand grip to the position as shown



Remove the track adapter as shown