STEP 1



Install the nozzle head on the pipe of the water outlet.

STEP 2



Twist the lamp into the nozzle head in the direction of the spiral teeth.

STEP 3



Connet the power supply and fixtures cable using IP connector. Make sure the waterproof is good.

STEP 4



Then lock the waterproof connector.

CONNECTION DIAGRAM