




Main Parts




- ① Solar panel
- ② Lampshade
- ③ Switch
- ④ PIR
- ⑤ Indicator light

Electrical Characteristics:

Solar panel: Monocrystalline
Rechargeable Battery: Li-ion Battery
Material: ABS & PC


How to install the device?

Fix the lamp on the wall with the screws.



Keep the solar panel face the sunlight directly to ensure it can charge the inside Li-ion battery effectively

Working process instructions



Switch

Press 1.5S for ON/OFF
Short press to change the lighting mode

Lighting mode indicator

Red LED :

- M1:** Blink one time
- M2:** Blink two times
- M3:** Blink three times

Lighting mode

- M1:** 100LM+PIR 1000LM(10S)
- M2:** 0+PIR 1000LM(10S)
- M3:** 300LM 6H