• Installation and wiring of luminaire must be in accordance with all applicable local codes.
• Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
• DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire.
• DO NOT install damaged product.
• Make sure electrical power is OFF before and during installation and maintenance.
• Make sure the equipment is properly grounded.
• Make sure the supply voltage is same as the rated fixture voltage.

Cut out in the right size:

MINIPOINT

86.D018.1***.** 35mm
86.D018.2***.** 35mm
86.D018.3***.** 50mm
86.D018.4***.** 50mm

MINIPOINT-A

86.D019.1***.** 47mm
86.D019.2***.** 47mm
86.D019.3***.** 62mm
86.D019.4***.** 65mm