




- Installation and wiring of luminaire must be in accordance with all applicable local codes.
- Installation, inspection, and maintenance of luminaires should be performed by a qualified electrician.
- **DO NOT** make or alter any open holes in the luminaire. Do not modify the luminaire.
- **DO NOT** install damaged product.
- Make sure electrical power is OFF before and during installation and maintenance.
- Make sure the equipment is properly grounded.
- Make sure the supply voltage is same as the rated fixture voltage.


## Main Parts





- ① Solar Panel
- ② Switch Button
- ③ Lamp Body
- ④ LED
- ⑤ PIR


Battery: Li-ion Battery  
Solar panel: Monocrystalline silicon  
Materials: ABS

## How to install the device?

- 


Take off the bracket from the lamp body
- 

Drilling and embedding the expansion screws into the wall
- 

Fix the bracket by screws onto the wall
- 

Hang the lamp body on the bracket

## Working process instructions



### Switch Button

- ON/OFF: Long press for 1.5S.  
(After the initial activation, the lamp will turn on/off automatically when dark/dawn.)
- Change lighting mode: Short press.

### Lighting Mode

- M1: 25% till dawn
- M2: 10%+PIR (30S)
- M3: 0+PIR (30S)
- M4: 100% till dawn