



**Precautions**

**Normal Operation:** The green LED indicator stays on when connected to mains supply. The indicator will turn off when the mains supply fails.

**Battery:** LiFePO4 rechargeable battery pack. Battery should be replaced when it reaches the end of its lifetime. To avoid damage to the luminaire and ensure its performance, the battery should be replaced with same type.

**Test Switch:** Press the test button, LED indicator will turn off and the luminaire will be powered by the battery pack. The light source is non-replaceable. When the light source reaches the end of its lifetime, the whole luminaire shall be replaced.

**Installation Procedure**

**WARNING**


1. Switch off before installation or maintenance.
2. Switch on only after complete installation and examination of the circuit.
3. Professional electrician for installation and maintenance only.
4. This luminaire is not intended for use in high-risk task area lighting.



Read instructions and check you have all the tools and accessories to complete the installation correctly.

**Recessed Mount**


1. Take off the battery cover and connect the battery.




2. Take off the terminal cover.




3. AC Power supply wiring, brown wire connects to L, blue wire connects N.



DALI Wiring



4. Fix the luminaire into ceiling.



5. Switch on, the green LED indicator will light up.



**Surface Mount**



**Change Lens**



**Photometric Data**

Mounting height	Oval lens for pathway application		Spacing (C0)		Spacing (C90)	
	3W	6W	Spacing (C0)	Spacing (C90)	Spacing (C0)	Spacing (C90)
2.5m	2.68m	3.1m	5.7m	6.5m	10m	21m
3.0m	2.8m	3.4m	6.5m	7.2m	10.5m	24m
3.5m	2.9m	3.5m	7.3m	7.8m	11.2m	25m
2.5m	3.1m	3.1m	6.5m	6.5m	11.2m	22.8m
3.0m	3.4m	3.4m	7.2m	7.2m	12.3m	25.3m
3.5m	3.5m	3.5m	7.8m	7.8m	13.2m	28m